


Installing Ek Mobile Thermal Printer drivers in Windows 8.1

Invoke Charms (take the mouse pointer to the upper right corner of the screen)


1. Invoke the Charms bar and click on Settings.




2. Clicking on “Change PC Settings”.



3. Click Update and Recovery.



4. Choose Recovery



Windows Update

You're set to automatically install updates.

We found new updates today, and we'll install them for you soon. We'll continue to check daily for newer updates.


[View details](#)

[Check now](#)

[View your update history](#)

[Choose how updates get installed](#)

5. Restart for Advanced startup



Refresh your PC without affecting your files

If your PC isn't running well, you can refresh it without losing your photos, music, videos, and other personal files.

[Get started](#)

Remove everything and reinstall Windows

If you want to recycle your PC or start over completely, you can reset it to its factory settings.


[Get started](#)

Advanced startup


Start up from a device or disc (such as a USB drive or DVD), change Windows startup settings, or restore Windows from a system image. This will restart your PC.

[Restart now](#)


6. In the list of options presented select “Troubleshoot”.




7. Choose Advanced options among the troubleshoot options.



8. Select Startup Settings




9. Click **Restart**.



10. Disable driver signing enforcement

The system will restart with the ability to let you choose which mode you'd wish to boot your system in. You'll be offered a few familiar options like Safe Mode and Debug mode. Here you have to choose option 7 by clicking the function key F7.



11. Install the printer driver.